

OEL Recommended Spare Parts List

C3600



Revision 3

Rev	Unit Name	No.	Part No.	Part Name	Q' ty /Unit	Recommended Q' ty/Year			Remarks	Special	Del/ Add	Remarks for environment
						per 500	per 1000	per 2000				
	C3600n	2	44005602	Frame-Assy. -OP PX742	1	2	4	8	ODA, OEL, AOS			-
	C3600n	12	43377003	PX732n Fuser Unit(OEL 230V)	1	15	30	60	C3600 OEL(230V) Pack in box			-
	C3600n	13	43192202	Plate Assy. -Base	1	2	4	8				-
	C3600n	14	43192602	Cassette-Assy	1	1	2	4				-
	C3600n	15	42088801	Frame-Separation-Assy.	1	3	6	12				-
	C3600n	16	42089001	Spring-Separation	1	3	6	12				-
	C3600n	17	43194101	Plate Assy-Side-R(PX732n)	1	2	4	8				-
	C3600n	18	43200101	Plate Assy-Side-L(PX732)	1	2	4	8				-
	C3600n	19	43362201	ACINLET-SW-JST3P	1	1	2	4	ACINLET-SWCord			-
	C3600n	21	43361901	CONN Cord-HRS12P-JST3P MOLEX10P	1	1	2	4	HeaterAC/IFCord			-
	C3600n	22	42062401	Gear-Idle-Belt(Z20-121)	1	1	2	4				-
	C3600n	23	43206103	Eject Assy. (PX742)	1	2	4	8				-
	C3600n	24	43204101	Sensor Assy. -Color-Regist(PX732)	1	2	4	8				-
	C3600n	25	2381028P0032	SMCD-17-210BD(1.0)	1	2	4	8	RearSensor_FFC			-
	C3600n	26	43214301	Spring-Torsion(L)	1	1	2	4				-
	C3600n	27	43214401	Spring-Torsion(R)	1	1	2	4				-
	C3600n	28	43207401	Shaft-Liftup	1	1	2	4				-
	C3600n	29	42060701	Bush	1	1	2	4				-
	C3600n	30	42066701	Gear-Planet-UP-L	1	1	2	4				-
	C3600n	33	43209301	Feeder-Assy. -Regist	1	2	4	8				-
	C3600n	34	43035201	PWR unit-High Voltage Purchase spec.	1	2	4	8	HighVoltage			-
	C3600n	35	2381028P0034	SMCD-12-180BD(1.0)	1	2	4	8	HighVoltage_FFC			-
	C3600n	36	43505401	PWR unit-ACDC Switch	1	2	4	8	230V			-
	C3600n	37	43198901	Motor-FAN(80)	1	1	2	4	FUSER			-
	C3600n	38	43823101	TB3 maintenance	1	2	4	8	C3600 Board-PUCU ODA, OEL, AOS			-
	C3600n	40	43215201	Cover-Rear	1	1	2	4				-
	C3600n	41	43215301	Cover-FaceUP	1	1	2	4				-
	C3600n	42	43215401	Cover-FaceUP-Sub	1	1	2	4				-
	C3600n	43	43215601	Cover-Side(R)	1	1	2	4				-
	C3600n	44	43215501	Cover-Side(L)	1	1	2	4				-
	C3600n	45	43209201	Cover-Front	1	1	2	4				-
	C3600n	46	43210701	Cover-Assy. -ManualFeed	1	1	2	4	C3600 ODA, OEL, AOS			-
	C3600n	47	43324602	Lever-Assy. -Front-Lock	1	1	2	4	600DPI			-
	C3600n	48	43295201	LED Head Unit-51STA	4	2	4	8				-
	C3600n	49	43197201	Plate-Lockout-ID	1	1	2	4				-
3	C3600n	50	43191809	Plate-name 742n	1	1	2	4	C3600 ODA, OEL			-
	C3600n	51	43216801	Plate-Logo	1	1	2	4				-
	C3600n	56	43215702	Cover-Rear-Bottom	1	1	2	4				-
	Top-Cover-Assy	2	43214801	Lever-Stack-L	1	1	2	4				-
	Top-Cover-Assy	3	43214901	Lever-Stack-R	1	1	2	4				-
	Top-Cover-Assy	6	43508801	RFID-UNIT Assy. - (Maintenance)	1	2	4	8	Board-RFIDR/W, Concurrent;a, b, c			-
	Top-Cover-Assy	11	43212901	Holder-Head (SH)	4	1	2	4				-

Rev	Unit Name	No.	Part No.	Part Name	Q' ty /Unit	Recommended Q' ty/Year			Remarks	Special	Del/ Add	Remarks for environ ment
						per 500	per 1000	per 2000				
	Top-Cover-Assy	12	43213001	Plate-FG-Head-L (SH)	4	1	2	4				-
	Top-Cover-Assy	13	43213101	Plate-FG-Head-R (SH)	4	1	2	4				-
	Top-Cover-Assy	15	43501005	Push-Nut (SPN-2. 6 A. C. P)	8	1	2	4				-
	Top-Cover-Assy	16	43213301	Cable-Assy. -Head	1	1	2	4	LED-HEAD-FFC RFID-FFC			-
	Top-Cover-Assy	17	43214002	Cover-Top	1	1	2	4				-
	Top-Cover-Assy	18	43214102	Cover-Top (Sub)	1	1	2	4				-
	Top-Cover-Assy	20	43214501	Cover-Hinge (L)	1	1	2	4				-
	Top-Cover-Assy	21	43214601	Cover-Hinge (R)	1	1	2	4				-
	Control-Panel-Assy	8	44005202	OR-PX7420PE (Cyrille)	1	2	4	8	Board-Opepanel ODA, OEL, AOS			-
	Control-Panel-Assy	9	2381028P0031	SMCD-7-400BD (1. 0)	1	2	4	8	OperationPanel_FFC			-
	Feeder_Unit	8	43135401	OR-Board-MIP	1	2	4	8	Board-FrontSensor			-
	Feeder_Unit	10	43361401	CONN Cord-AMP5P-AMP5P	1	1	2	4	FrontSensorCord			-
	Feeder_Unit	11	43209601	Cover-SNS	1	1	2	4				-
	Plate Assy-Side_R	4	43614901	OR-Board-PRS	1	2	4	8	Board-TonerSensor			-
	Plate Assy-Side_R	5	2381028P0030	SMCD-10-280BD (1. 0)	1	2	4	8	TonerSensor_FFC			-
	Plate Assy-Side_R	7	43195101	Motor-DC-ID-M58	1	1	2	4				-
	Plate Assy-Side_R	8	43361601	CONN Cord-AMP10P- AMP10P	1	1	2	4	DC-IDMotorCord			-
	Plate Assy-Side_R	9	43353101	OR-Motor-Pulse-Liftup	1	1	2	4				-
3	Plate Assy-Side_R	11	43196201	Gear Assy. -Planet	1	1	2	4	Around Fuser			-
3	Plate Assy-Side_R	12	43196601	Gear-Idle-Heat (Z14- 102)	1	1	2	4	Around Fuser			-
3	Plate Assy-Side_R	13	43196701	Gear-Idle-Z35	1	1	2	4	Around Fuser			-
	Plate Assy-Side_R	19	43353001	OR-Motor-Pulse-HOP	1	1	2	4				-
	Plate Assy-Side_R	20	43361501	CONN Cord-AMP4P-AMP4P	1	1	2	4	HoppingMotorCord			-
	Plate Assy-Side_R	21	42058303	Solenoid	1	1	2	4				G
	Plate Assy-Side_R	23	43197801	Motor-Pulse-Fuser	1	1	2	4				-
	Plate Assy-Side_L	2	43352901	OR-Motor-Pulse-Belt	1	1	2	4				-
	Plate Assy-Side_L	4	43415601	Microswitch Assy. - PX732	1	2	4	8	CoverOpenSwitchAssy			-
	Plate Assy-Side_L	5	43201001	Link-LiftUp-L	1	1	2	4				-
	Plate Assy-Side_L	7	43361502	CONN Cord-AMP4P-AMP4P	1	1	2	4	BeltMotorCord			-
	Sensor_Assy- Color_Regist	2	43135301	OR-Board-ZAK	1	2	4	8	Board-RearSensor			-
	Sensor_Assy- Color_Regist	4	5654200P0001	GP2TC2J000F	1	3	6	12	DensitySensor			G
	Sensor_Assy- Color_Regist	5	43361701	CONN Cord-MOLEX5P- MOLEX5P	1	1	2	4	DensitySensorCord			-
	Base-Assy	11	43334801	Roller Assy. -Sub	1	1	2	4				-
	Base-Assy	23	43334901	Roller Assy. -Hopping	1	1	2	4				-
	Eject-Assy	2	43206401	Lever-Eject-Sensor	1	1	2	4				-
	Eject-Assy	4	40135301	Photo-Interrupter	1	1	2	4	ExitSensor			G
	Eject-Assy	5	43361801	CONN Cord-AMP3P-AMP3P	1	1	2	4	ExitSensorCord			-
	Eject-Assy	10	43649701	Sponge-Roller-FD	2	2	4	8				-
	Eject-Assy	11	43206901	Shaft Assy. -Eject (FU)	1	1	2	4				-
	Eject-Assy	12	43207201	Shaft Assy. -Eject (FD)	1	1	2	4				-